


# INSTALLATION OPTION

## *Instruction Card for THEATER 1001*



12 dB Pad



DC Supply

Theater 1001 Modulator

If after you install the Theater 1001 modulator and you notice the picture quality on your TV is negatively affected, especially in the lower range channels, you will need to add the 12 dB pad to the modulator. Proceed with the following instructions below.

### **Application Instructions:**

- A. Remove incoming cable from the modulator plug identified as the "TO TV" port.
- B. Insert the 12 dB pad between the modulator and incoming cable, making sure to retighten all connections. See **Fig. 1** below.



**Connect 12 dB Pad  
to "TO TV" port**